Playtime/Vuelta Centre Foot - Assembly Instructions

The centre foot can be assembled if required.

Assembly of Playtime/Vuelta centre foot:

- Lay the sofa on its back (protect the frame from dirt!).
- In the middle of the sofa, feel for a threaded screw underneath the bracing fabric (1).
- Cut out the threaded screw underneath the bracing fabric (2 + 3).
- Mount the centre foot. Make sure the adjustment screw is at it's starting point (screwed in Clockwise).
- Turn the sofa in it's upright position.
- Adapt the black adjusting screw (counter-clockwise) until it touches the floor.

ATTENTION: NEVER MOVE THE SOFA WITH THE ADAPTED ADJUSTING SCREW!

1

2

3



4



5

Adjustment screw